

2007-2014 Toyota Tundra

RCT0777QC, RCT0786QC, RCT0792QC-6, RCT07107QC, RCT07107QC-6, RCT0786CC, RCT0792CC-6

Bolt Kit

- (12) 8mmx25mm Hex Bolts
- (12) 5/16" Flat Washers
- (12) lock washer

Recommended Tools

- Socket Set



Step 1. Remove any factory hardware and discard. Position the Nerf Step on the side of the vehicle (figure 1). **NOTE:** The short end of the Nerf Step goes to the front of the vehicle. Test fit the Nerf Step to the factory bolt hole locations. **NOTE:** The step should line up with the existing factory bolt locations.

Step 2. Starting with one of the center brackets, start the 8mm hex bolt, 8mm lock washer and 8mm flat washer into the factory bolt locations and hand tighten (figure 2). Start all of the remaining 8mm hex bolts, 8mm lock washers and 8mm flat washers. Torque each bolt location to 15ft/lbs.

Step 3. Repeat installation procedures on the passenger side.

This concludes the installation



Figure 1



Figure 2

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items