



Installation Instructions TrekStep™

Vehicle Application

• Toyota Tundra 2007 – Current Part Number: 75305-15

www.bestop.com - We're here to help! Visit our web site and click on "Ask a Question". Click here for more Truck Accessories by Bestop.









WARNING Do not rely in any way on the components of this product to protect against injury or death in the event of an accident. Never operate the vehicle in excess of manuracturer's specifications.

WEAR SEAT BELTS AT ALL TIMES

Read and follow, precisely, all installation instructions provided when installing product. Failure to do so may result in a poor fit and could place occupants of the vehicle in a potentially dangerous situation.


Parts List and Hardware Identification






Part Number 514.10, Qty - 1











M10 Washer, Part Number 473.20, Qty - 2

M6-1.0 x 20 Socket Cap Screw, Part Number 470.00, Qty - 3





M10-1.5 x 45mm Partial Thread Hex Head Screw, Part Number 487.20, Qty - 2

M10-1.5 x 65 Partial Thread Hex Head Screw, Part Number 476.02, Qty - 2




2014 - Current Models Only 2013 or earlier skip to Step 7



Remove Small Support Bracket

Locate the small support bracket on drivers side of vehicle. Use an M12 socket or wrench to remove the bolts from support bracket. Remove the bracket from the vehicle.




2014 - Current Models Only



Remove Large Bumper Support Bracket

Locate the large bumper support bracket on drivers side. Use an M13 wrench or socket to remove the 3 bolts that attach bracket to the frame and bumper.




Rev. H 0115 75305 pg. 2

2014 - Current Models Only



Remove Plastic Rivet

Remove the plastic rivet in bottom of bumper that is holding the bumper cap.



2014 - Current Models Only




Release Bumper Clips

Remove bumper caps from bumper to remove 2 bolts holding bumper bracket. From the bottom side of bumper, use a flat head screwdriver to release clip from bumper slot. Gently pull up on bumper caps from the top until clips come free of bumper.

NOTE

There are a total of 10 clips that will need to be removed from bumper.

The corner bumper cap will come completely free, the center bumper cap will only need to come up far enough to reach the bumper bracket bolt.




2014 - Current Models Only



5 Remove Bumper Bracket Bolts

Use an M12 wrench to remove the 2 bumper bracket bolts on top of bumper.




2014 - Current Models Only




6 Remove Bumper Bracket

Remove the bumper bracket from vehicle. Store the bracket to be used if the Step is removed.



Locate Rear Bumper Attachment


Locate the rear bumper attachment point on the driver's side of the vehicle.



Rev. H 0115 75305 pg. 3

8 Remove Bumper Fasteners

Remove the bumper fasteners. Set them aside to be reused.




10 Install Linkage to Mounting Bracket

Use two (2) M10 x 45 mm Partial Thread Hex Head screws to secure the Linkage to the Mounting Bracket.


2014 – Current Models: Secure the slotted end of the Side Bracket to the outside bolt.

2013 and Earlier Models: Do not use the Side Bracket



9 Install Mounting Bracket


Align the holes in the Mounting Bracket with the holes on the vehicle. Reinstall the fasteners removed in Step 8.



2014 - Current Models Only

Secure Side Bracket to Bumper

Use an M8-1.25 U-Nut and one (1) OE bolt removed in Step 2 to secure the Side Bracket to the bumper.




Rev. H 0115 75305 pg. 4

2014 - Current Models Only

Reinstall the Small Support Bracket

Reinstall the bracket that was removed in Step 1.




2014 - Current Models Only




13 Reinstall the Bumper Caps

Line up plastic clips on bumper caps. Press down firmly to lock into place.



Install Step

Use the M6-1.0 x 20 Socket Head Cap Screws to mount the Step to the Linkage Assembly.




15 Step Adjustment

Once the Step is installed on the vehicle, you may adjust it as desired.

If necessary to adjust the height, use the three (3) 1/4" Spacers provided. Remove the M10-15 x 65mm Hex Bolts installed in earlier and place the 1/4" Spacers between the Frame Mount and the Linkage. Reinstall the Hex Bolts.

When the Step is in the desired position tighten all nuts.



Rev. H 0115 75305 pg. 5

Operation

- The TrekStep[™] is foot operated and deploys and retracts with a nudge of your foot.
- To deploy, press down using your left foot, on the forward outside corner of the step pad.
- To retract, gently kick the underside of the step pad.
- Max Load Capacity: 300 lbs.
- Always use appropriate hand holds when stepping up to or down from your vehicle's cargo bed.

Care and Maintenance

The step pad surface and linkage arms should be washed with mild soap and water using a soft brush or sponge to dislodge any mud, dirt or accumulated road grime. Rinse with fresh water. After it is dry, lubricate the hinge with 3-IN-ONE Oil.

To prevent slipping, avoid applying waxes, lubricants or protectants like Armor All® to the step surface.

Attention!

TrekStep™ SHOULD ALWAYS BE STOWED IN THE RETRACTED POSITION WHEN DRIVING.

LIMITED WARRANTY

We warrant our product to be free from defects in material and workmanship, for the terms specified below, provided there has been normal use and proper maintenance. This warranty applies to the original purchaser only. All remedies under this warranty are limited to the repair or replacement of any item or items found by the factory to be defective within the time period specified. If you have a warranty claim, first you must call our factory at the number below for instructions. You must retain proof of purchase and submit a copy with any items returned for warranty work. Upon completion of warranty work, if any, we will return the repaired or replaced item or items to you freight prepaid. Damage to our products caused by accidents, fire, vandalism, negligence, misinstallation, misuse, Acts of God, or by defective parts not manufactured by us, is not covered under this warranty.

THE WARRANTY TIME PERIOD IS AS FOLLOWS FOR ALL TrekSteps™ MANUFACTURED BY OUR COMPANY: THREE YEARS / 36,000 MILES FROM DATE OF PURCHASE.

ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE CREATED HEREBY ARE LIMITED IN DURATION TO THE SAME DURATION AND SCOPE AS THE EXPRESS WRITTEN WARRANTY. OUR COMPANY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



For further information or request for warranty work, please contact:

Bestop Inc. Customer Service Toll-Free: (800)845-3567 Main: (303)465-1755

E-mail: csbestop@Bestop.com Website: www.Bestop.com

Rev. H 0115 75305 pg. 6