



baja designs[®]
The Scientists of Lighting

Can-Am, Maverick X3 OnX6 Shock Mount Kit

44-7089



Baja Designs • 185 Bosstick Blvd. • San Marcos • CA • 92069

Phone 760.560.2252 • Fax 760.560.0383 • info@bajadesigns.com

www.bajadesigns.com

LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all of the products that we manufacture.



baja designs[®]
The Scientists of Lighting

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and be able to supply proof of purchase.

Li-Ion or Li-Po Batteries: carry a 2 year warranty.

NiCad DSK Batteries: carry a 90 day warranty

Dual Sport Kit Switches: carry a 1 year warranty.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a particular purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Indemnification:

Buyer hereby acknowledges off roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.

Customer satisfaction stands at the core of who Baja Designs is as a company. BD gives you a full 30 days to test out your new light and if you are not 100% satisfied with your purchase, you can send it back for an exchange or refund of the purchase price and applicable tax.



baja designs
The Scientists of Lighting

Exclusions:

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Instructions for Can-Am, Maverick X3 S8 Shock Mount Kit.

1. Remove Hood. The hood is held in by 5 rubber grommets. Begin by gently pulling up on the rear of the hood. Work your way towards the front to fully remove the hood.



2. Next, remove the two 10mm bolts at the front of the shock mount holding the radiator support on. This will require a 10mm socket and a 10mm wrench behind the shock tower.
3. Place the Shock mount with the horns facing forward and push the two existing 10 mm bolts through the two holes with the provided washers. Place the two





baja designs®
The Scientists of Lighting

nylon locknuts on the back of the bolts and tighten until snug. Be sure to center your bracket with the shock mount.

4. Re-attach the hood by pressing firmly over each grommet location, begin at the front of the vehicle.
5. Attach the light by with the four ¼"-20 bolts on each side of the light (if installed) There should be two ¼"-20x 5/8" bolts go towards the front of the light, while the ¼"-20x 1.25" will be towards the back



6. Adjust the light to the desired angle and snug bolts down.

(See wiring harness instructions for your electrical instructions.)